

### IMPORTANT NOTE


This quick guide is a summary of the complete installation manual. The manual contains safety warnings and other explanations which must be taken into account. The most recent versions of this guide and the installation manual are available at the "Downloads" section on Erreka's website. <http://www.erreka.com>

The options and functions described in this guide apply for the firmware version indicated on the circuit. The firmware, as part of a process of continuous improvement, is subject to new functionalities or upgrades being included as a result of new versions which are not necessarily compatible with previous ones. For this reason, some options or functions may differ or be unavailable if your firmware is older than shown in this guide.

### Elements of the complete installation

#### Electrical cabling


- A: Main power supply
- B: Flashing light
- C: Photocells (Tx / Rx)
- D: Key switch



E136A

### Unlocking

**⚠** Unlocking should be carried out with caution. If the barrier is not balanced or the arm is not mounted, the internal spring may cause a violent movement.



D136A

#### Unlocking (manual operation):

turn the wing knob (P) clockwise until it stops.


#### Lock (motorised operation):

turn the knob (P) anti-clockwise until it locks.


### Arm assembly

✎ The barrier is supplied for assembly to the right. For assembly to the left, carry out the "Changing side" (see next page) before mounting the arm.

- 1 Lock the operator and mount the first section.
- 2 Unlock the operator and manually lower the arm.
- 3 Lock the operator and mount the second section.



P136C1




NTS424E: S= 70cm  
NTS624E: S= 60cm

P136C2

## Changing side

Right barrier

Left barrier




E136D

## Balancing

**THE BARRIER MUST BE BALANCED FOR PROPER OPERATION.**


- Unlock the operator and tighten the spring until the barrier is balanced at 45°.



P136G


## General connections

- DL13 24Vdc power supply
- DL36 5Vdc power supply
- DL37 Closing relay activated
- DL38 Opening relay activated



P136F

## Display indications



**D1 and D2:**


- |                |                                      |
|----------------|--------------------------------------|
| CL (static)    | Barrier closed                       |
| CL (flashing)  | Barrier closing                      |
| OP (static)    | Barrier open                         |
| OP (flashing)  | Barrier opening                      |
| XX (countdown) | Barrier on standby                   |
| STOP           | Operator unlocked                    |
| PR (static)    | Pause (operation not complete)       |
| rs (static)    | Barrier searching for close position |

**D3 and D4:**

- |       |                                 |
|-------|---------------------------------|
| CS    | Closing safety device activated |
| E I   | Encoder motor halted            |
| F I   | Thrust limit exceeded           |
| bA    | Battery working                 |
| Ft no | Photocells defective (testing)  |


## Rotation direction change and check (C I)

☞ This operation is only necessary if the barrier opens instead of closing when making a reset (r5).




## Radio code programming, P I (only with RSD receiver)

☞ If a receiver other than RSD is used, see the corresponding instructions.





## The travel of the barrier must be programmed for correct operation

### Open/close programming (P3)



## Complete programming chart

D1	D2	Parameter	D3	D4	Pre-determined option	Options or values
C	1	Motor turning direction	0	1	x	
			0	2		
	4					Disabled
	5	Closing safety device (photocell or strip)	0	0	x	Device not installed
			1	0		Device without testing
1			1		Device with testing	
P	1	Total opening radio code programming	0	n		
	2					Disabled
	3	Barrier open/close programming	0	n		
F	1	Functioning mode	0	1		Automatic
			0	2	x	Step-by-step
	2	Standby in automatic mode	0...5	0...9	15	59 = 59 sec.; 25 = 2 min. 50 sec., etc
	3				Disabled	
R	0	Flashing light	0	1	x	No warning
			0	2		With warning
	1	Garage light time	0...5	0...9	03	59 = 59 sec.; 25 = 2 min. 50 sec., etc
	2	Barrier speed	0	1...5	03	01: minimum speed; 05: maximum speed
	3	Slow down speed	0	1...5	02	01: minimum speed; 05: maximum speed
	4	Slowdown distance	0	0...5	00	00: minimum distance; 05: maximum distance
	5					Disabled
	6	Maximum thrust	0...1	0...9	05	01: minimum thrust; 10: maximum thrust
	7	Closing <b>photocell</b> used during standby (in automatic mode only)	0	1		Immediate close
			0	2	x	Restart standby time
			0	3		Has no effect
	8	<b>Pushbutton</b> operation during standby (in automatic mode only)	0	1		Immediate close
			0	2	x	Restart standby time
			0	3		Has no effect
	9	Opening mode	0	1	x	Opening in accordance with the mode selected in the main functions (F)
0			2		<b>Collective opening</b> (the control board does not obey the commands during opening)	
0			3		<b>Step-by-step opening</b> (the barrier halts if a key command is activated during opening. The barrier closes if activated again)	
n	1	Operations carried out	X	X		Indicates the cycles completed, multiplying the indicated figure by an amount, for example: 68 indicates 6,800 cycles completed 68 indicates 68,000 cycles completed