

## ACCESORIES

Rev: 04

## SENSORS AND PUSH BUTTONS

N°	PICTURE	ITEM	CÓDE
1	doorlearn	ACTIVE INFRARED SENSOR WITH BARRIER INCLUDED EN16005 TüV CERTIFIED (HR100-CT-ERK/BL) "Active infrared sensor for the detection and opening, with great capacity to regulate sensing field, includes photocell curtain for better jamming protection, vertical surface assembly". TUV Certified UNE - EN16005"	RAD17
2	C Erreika	SENSOR BLACK HR942D "Active infrared sensor for the detection and opening , with great capacity to regulate detection field, vertical surface assembly."	RAD3
3	E RREKA	MICROWAVE SENSOR LC (HR-50-ERK) "Microwave Sensor"	RAD9
4	C ERREKA	MICROWAVE RADAR (BIDIRECTIONAL ERREKA- SEAGLE TWO) "Radar with bidirectional microwave detection technology to activate the automatic door"	RAD8
5		SWING DOOR SAFETY SENSOR SSS-3 LENGTH: 350 "Presence sensor to ensure the path of a swing door"	RAD6
6		INFRARED SENSOR WITH WIDE DETECTION CAPACITY, INCLUDES SECURITY PHOTOCELL (HR 98i-8M) UP TO 4m. HEIGHT "Active infrared sensor to detect and opening, with great capacity to regulate sensing field, includes photocell curtain for better jamming protection, vertical surface assembly".	RAD11
7	C ERREKA	ACTIVE INFRARED SENSOR WITH BARRIER INCLUDED SSR3 "Sensor microwave detection and opening, with great capacity to regulate sensing field, includes photocell curtain for better jamming protection, vertical surface assembly".	RAD12



## ACCESORIES

Rev: 04

## SENSORS AND PUSH BUTTONS

N°	PICTURE	ITEM	CÓDE
8	C ERREKA	MICROWAVE SENSOR, LC UNIDIRECTIONAL (HR-50-UNI-ERK) "Microwaves Sensor"	RAD19
9	PRESS TO QPEN	Push button with wheelchair logo (128mm x 128mm) "Push button with wheelchair logo"	PUL03
10		Elbow push button -silver: 192mmx41,5mm "Push elbow for automatic door activation, finished in silver and measures 190mm x 41,5mm."	PUL05
11		TOUCHLESS SWITCH (MICROWAVES) "Proximity Microwaves sensor"	PUL06
12		BPL2 PHOTOCELL "Active security photocell"	FOT3
13	C ERREKA	PRESENCE ACTIVE INFRARED SENSOR 2 (HR94D1-C1-ERK/BL) "Active presence sensor to ensure the path of the moving door"	FOT9
14	PUSAR	4 STICKERS KIT FOR ACTIVATION WITH FOT9 "4 Sticker Kit "push" in order to be used in the activation of the curtain FOT9"	FOTP