


LISTA DE REPUESTOS / SPARE PARTS LIST

LISTA DE REPUESTOS / SPARE PARTS LIST

		HP4000C
A	CONJUNTO REDUCTORA / reducer ensemble	SHP01
B	CONJ. EJE DE SALIDA Y DESBLOQUEO CON ENGRANE / output shaft and unlocking ensemble with gear	SHP02
C	ENGRANE SALIDA / output gear	SHP03 (M4-Z20)
D	CONJUNTO MOTOR ELECTRICO / electric motor ensemble	SHP04
E	CONJ. MICRORUPTOR FINAL DE CARRERA / limit switch ensemble	SHP05
F	CONJ. ACCESORIOS FINAL DE CARRERA / limit switch accessories ensemble	SHP06
G	CONJ. CUERPO EXTERIOR C/TAPA SIN CERRADURA/ external body ensemble with front panel without lock	SHP07
H	MICROSWITCH TAPA FRONTAL / front panel microswitch	SHP08
I	CONJ. CERRADURA COMPLETA CON LEVA C/LLAVE / complete key cylinder ensemble including lever and key	SHP09
J	TAPA SUPERIOR CUERPO / top body cover	SHP11
K	CONJUNTO PLACA BASE REDUCTORA / reducer base plate ensemble	SHP12
L	LLAVE ALLEN 6 / 6 Allen key	26A049

		ACCESORIOS accessories
C	ENGRANE SALIDA / output gear	AHP02 (M6-Z15)
M	CONJUNTO PLACA DE FIJACIÓN / base plate ensemble	AHP01