


# LISTA DE REPUESTOS / SPARE PARTS LIST



	NASR70E	NASR100E	NASR100EM
A	TAPA LEDS / <i>led's cover</i>		
B	CARCASA / <i>plastic housing</i>		
C	CIRCUITO DISPLAY / <i>display board</i>		
D	CIRCUITO LEDS / <i>led's board</i>		
E	CIRCUITO POTENCIA / <i>power board</i>		
F	CUADRO MANIOBRA / <i>control board</i>		
G	170232	170231	170268
H	170230	170229	170337
I	BASE / <i>base</i>		
J	CASQUILLO ADAPTACION / <i>gearmotor shaft adaptor</i>		
K	CONJUNTO PIÑON / <i>motor-drive rail sprocket</i>		
L	BRIDA AMARRE GUIA / <i>rail fixing bracket</i>		
M	CABLE CON ENCHUFE / <i>cable with plug</i>		170296
N	SOPORTE PARED / <i>rail fixing bracket to the wall</i>		
O	CONJUNTO TENSOR / <i>pulley-tightener assembly</i>		
P	SOPORTE INTERMEDIO GUIA / <i>intermediate rail fixing bracket</i>		
Q	SOPORTE PUERTA / <i>arm fixing bracket to the door</i>		
R	BRAZO CURVO GUIA / <i>curved arm</i>		
S	TOPE MECANICO / <i>stopper</i>		
T	CARRO DE ARRASTRE / <i>carriage</i>		
U	ENGANCHE DE CADENA / <i>chain connector</i>		
V	TORNILLOS FIJACION ACCIONAR GUIA / <i>motor-rail fixing bolts bag</i>		
W	TORNILLOS FIJACION PUERTA-PARED-TECHO / <i>door-wall-roof fixing bolts</i>		
X	ENCODER / <i>encoder</i>		